

Pennsylvania Dental Association Revised December 2013

Reviewed by the Pennsylvania Department of Environmental Protection

- Radiation in the Healing Arts is an invaluable tool with many obvious benefits.
- Although greatly beneficial, radiation can pose serious health risks to patients and equipment operators if not used properly.
- In addition to risks caused by improper practices, Americans face a much higher risk of developing cancer due to overuse of radiation for medical testing.



www.padental.org

- The critical importance of safe and effective use of radiation in the Healing Arts, while reducing risks to patients and equipment operators, has resulted in government oversight/regulation, including regulation of dental offices and personnel.
- Oversight/regulation by government is handled by agencies administering and enforcing laws and regulations.



www.padental.org

- In Pennsylvania, the two regulatory agencies are:
 - The Department of State
 - The Department of Environmental Protection
- The two governing statutes are:
 - The Dental Law, 63 P.S. § 120, et seq.
 - Radiation Protection Act, 35 P.S. § 7110.101, et seq.





- Pennsylvania Department of State
 - Administers and enforces The Dental Law, which provides for initial licensure and certification requirements for dental professionals
 - Handled through the Department of State, Bureau of Professional and Occupational Affairs





- Pennsylvania Department of Environmental Protection (DEP)
 - Administers and enforces the Radiation Protection Act (aka the "X-Ray Law"), which provides for equipment registration and inspections, and ongoing training requirements for personnel operating X-ray equipment
 - Handled through the Department's Bureau of Radiation Protection



www.padental.org

- In addition to administering and enforcing the two governing statutes, the Department of State and the DEP both have regulations to implement these statutes.
- Regulations, like statutes, have the force and effect of law.
- Policies, or "Technical Guidance" (the term used by the DEP), also guide agency action and interpretation of law, but do not themselves have force of law.





- Nearly all regulatory issues concerning X-rays in dental offices are addressed by DEP under the Radiation Protection Act (RPA), which became law in 1984.
- RPA governs "radiation sources," such as X-ray equipment; and "radiation source users," which includes any person who owns or is responsible for a radiation source.
- RPA gives broad regulatory powers to DEP.





Radiation Protection Act

- Regulation of X-rays in dental offices is handled under DEP's regulations entitled "X-RAYS IN THE HEALING ARTS".
- Regulations are found Pennsylvania's Administrative Code, <u>25 Pa. Code Chapter 221</u>.
- In 1998, additional regulations were promulgated which included an "Appendix A" to address training and competency for individuals who operate X-ray equipment.





Radiation Protection Act

• Chapter 221 requires verification of initial competence and ongoing continuing education.

• Determination of initial competence is based on 11 factors.





Determination of Competence

- Individuals shall be trained and competent in the general operation of the X-ray equipment, and in the following subject areas:
 - Basic properties of radiation
 - Units of measurement
 - Sources of radiation exposure
 - Methods of radiation protection
 - Biological effects of radiation exposure
 - X-ray equipment
 - Imaging and processing
 - Patient exposure and positioning
 - Procedures
 - Quality assurance program
 - Regulations





Initial Competency Verification

- Any individual who satisfies the requirement of the Department of State Professional and Occupational Standards to practice in his or her discipline is deemed by DEP to have met the initial competency requirement.
- DEP recognizes that the Department of State determines initial competency requirements not only for physicians/dentists, but "auxiliary personnel" as well.



www.padental.org

Continuing Education

In addition to the initial determination of competence, the regulations further state that, "there shall be continuing education in radiation safety, biological effects of radiation, quality assurance and quality control."





• Written safety procedures and rules shall be available at all facilities, including descriptions of the operating technique required for the safe operation of the particular X-ray system.

• The operator shall be familiar with the rules.





- Review patient's medical history and physical condition prior to taking X-rays.
- Be willing to accommodate needs of the patient.
- Verify non-pregnancy of female patients prior to taking X-rays.
- Postpone elective x-rays until pregnancy is over.
- Inquire about any past radiation therapy.
- If a patient has a history of large radiation exposure over the last two years, elective radiographs should be minimized.



- All ionizing radiation is harmful. To protect the patient and the operator from excess exposure, radiation exposure guidelines have been established.
- The amount of radiation that reaches the body of the operator can be measured through use of a monitoring device known as a film badge.





- Radiation is measured in units called the sievert or gray (formerly known as rem or rad).
- Maximum permissible dose ("MPD") recommendations specify the dose limits for exposure to the ionizing radiation without tissue damage.
- The MPD for those who work with radiation is 0.05 sievert/year (System International – SI Units) or 5.0 rems/year. For the public, it is 0.001 Sv/year or 0.1 rem/year. The MPD for operators who are pregnant is 0.001 Sv/year or 0.1 rem/year, for the entire pregnancy.



• Effective Dose (Sv)

The effective dose is used to estimate risk in humans. It allows the risk from exposure to one region of the body to be compared with the risk from exposure to another region. It also considers the radio sensitivities of different tissues for cancer formation or heritable effect.





Summary of Radiation Quantities and Units

**Data from The NIST reference on Constants, Units and Uncertainty

Quantity	SI Unit	Conventional Unit	Conversion
Exposure	Coulomb/	Roentgen (R)	1C/kg=
	kilogram		3876 R
Absorbed	Gray (Gy)	rad	1Gy=
dose			100rad
Equivalent	Sievert (Sv)	rem	1 Sv=
dose			100 rem
Effective	Sievert (Sv)		
dose			





I. Radiation Safety Kilovoltage

- A kilovolt is a measure of electrical current and is equal to 1000 Volts.
- The higher the voltage, the more energetic (thus a higher penetrating potential) the X-ray will be.
- Lower energy X-rays are absorbed by the body and objects through which they pass.
- X-rays that are absorbed do not make it to the film to create an image.





I. Radiation Safety Kilovoltage

- Kilovoltage peak (kVp) is the maximum amount of voltage used in an X-ray machine.
- Some machines can be adjusted from 50 to 100 kVp.
- Other machines are preset to 70 kVp.
- Settings below 60 and above 85 kVp are rarely used in dentistry.





I. Radiation Safety Kilovoltage

- Every 15% increase in kV, will cause a doubling in the exposure or radiographic density.
- Going from 70 to 80 kVp would double the exposure. To compensate, the exposure time would have to be decreased by half.
- Going from 70 to 60 kV would decrease the exposure by half. To compensate, the exposure time would need to be doubled.



I. Radiation Safety Milliamperage

- A milliampere (mA) is measure of electrical current and is equal to 1/1000A
- The higher the amperage, the higher quantity of X-rays there will be.
- Some machines can be adjusted from 10 to 15 mA.
- Some machines are preset to 6 or 7 mA.





- Utilization of proper equipment aids in limiting the amount of radiation dental patients receive.
- The dental X-ray tubehead must be equipped with appropriate aluminum filters, lead collimator, and position-indicating device.
- State and federal laws regulate the required thickness of the aluminum filters. Machines that operate below 70 kVp require a minimum of 1.5mm aluminum thickness if manufactured after December 1, 1980.
- Machines manufactured before December 1, 1980 require a minimum of 0.3mm if operating below 51 kVp and a minimum of 1.2mm if operating between 51 kvp – 70 kVp.
- All Machines operating above 70 kVp require a minimum of 2.1mm aluminum thickness.
- Collimation is used to restrict the size and shape of the X-ray beam. It is a lead plate with a hole in the middle and is fitted over the opening of the machine housing where the X-ray beam exits the tubehead.



www.padental.org

- The position-indicating device (PID) appears as an extension of the X-ray tube and is used to direct the X-ray beam.
- There are three types of PIDs:
 - Conical (no longer used in dentistry)
 - Rectangular
 - Round





- Rectangular and round PIDs are available in varying lengths from short (8") to long (16").
- The long PID is preferred.
- The rectangular type is the most effective in reducing patient exposure and can reduce patient dose by 60 %.
- Thyroid collars, lead aprons, fast film, and filmholding devices all reduce radiation received by the patient.



- The lead thyroid collar protects the thyroid gland from scatter radiation.
- The lead prevents radiation from reaching the highly radiosensitive tissues of the thyroid.
- The thyroid collar may be separate or connected to the lead apron.
- The thyroid collar is recommended for all intraoral films. It is not recommended for extraoral films because it obscures information on the film (example – panorex).



- Intensifying Screens and Film
 - Extraoral films are typically screen films and require the use of intensifying screens and a cassette for exposure
 - The two most common extraoral films include panoramic and cephalometric films
 - Rare earth intensifying screens are recommended combined with high speed film of 400 or greater. (ADA 2006)
 - Rare earth screens decrease patient exposure by as much as
 55% in panoramic and cephalometric radiology.





Source to Skin Distance
Use of a long source-to-skin distance of 40cm rather than shorter distances of 20cm, decreases exposure by 10 to 25%. Distances between 20cm and 40cm are appropriate, but the longer distances are optimal. (ADA 2006)





- Fast film is the most effective method of reducing a patient's exposure to radiation.
- Fast film is available for intraoral and extraoral radiography.
- F-speed is the fastest intraoral film currently available. It offers a 60% reduction over D-speed film.
- Do not use film slower than D-speed.
- Current digital sensors offer greater or equal dose savings.





- The dentist must prescribe X-rays based on individual needs.
- The dentist uses professional judgment to determine the number, type, and frequency of the dental radiographs.
- The ADA, in conjunction with the FDA, has adopted guidelines for prescribing X-rays.





• There are three guiding principles in radiation protection:

principle of justification
 principle of optimization
 principle of dose limitation





Principle of Justification

- obligates the dentist to do more good than harm

 dentist should identify situations where the benefit to the patient from diagnostic exposure exceeds the low risk of harm





Principle of Optimization

 holds that dentists should use every means to reduce unnecessary exposure to their patients and themselves

- This philosophy of protection is known as the principle of ALARA (As Low As Reasonably Achievable).





Principle of Dose Limitation

- Dose limits are used for occupational and public exposures to ensure that no individuals are exposed to unacceptable high doses.





I. Radiation Safety Minimizing Radiation

- Use fastest film possible
- Expose as few films as possible
- Use correct exposure values
- Use film aiming devices
- Process films correctly
- Use appropriate filters
- Consult doctor if film is flawed or has artifact





I. Radiation Safety Operator

- The dental radiographer must use proper protection measures to avoid occupational exposure.
- Proper procedures include:
 - Avoid the primary beam
 - Stand at least 6 feet away from the X-ray tubehead
 - Stand in the safe zone which is 90-135 degrees from the direction of the primary beam
 - Never hold a film in place during exposure
 - Never hold the tubehead during exposure





- All ionizing radiations can produce biologic changes in living tissues and must be used judiciously.
- Although the amount of X-radiation used in dentistry is very small, biologic damage can still occur.





- Not all X-rays pass through the patient to reach the dental X-ray film.
- Some X-rays are absorbed by the patient's tissues.
- Chemical changes can occur that result in biologic damage.





There are two types of radiation injury that can occur:

Ionization
 Free radical formation





Ionization

- May occur when X-rays strike a patient's tissues
- Causes formation of a positive atom and a dislodged negative electron
- The excited electron can cause a chemical change in the cell that results in biologic damage
- Ionization has little effect if the chemical changes do not alter sensitive molecules
- Can cause substantial changes in DNA





Free Radical Formation

- X-radiation may cause the formation of free radicals, which are the primary cause of cell damage
- Highly reactive and unstable atom
- May recombine with other free radicals to cause cell damage
- May combine with ordinary molecules to form a toxin





• <u>Short Term Effects</u> – large amounts of radiation delivered in minutes, days, or weeks. Not applicable to dentistry.

• <u>Long Term Effects</u> – small amounts of radiation absorbed repeatedly over a long period of time.



www.padental.org

II. Biological Effects of Radiation Patient Exposure and Dose

- Patient dose from dental radiography is usually reported as the amount of radiation received by a target organ. Although actual exposures vary considerably, dental exposures are a small fraction of the annual average background exposure.
- The most radiosensitive target organs commonly studied include bone marrow, thyroid gland, brain, and salivary glands.





Sources of Ionizing Radiation

Natural (background)
 Technologically induced





Annual Estimated Average Effective Dose Equivalent Received by a Member of the Population of the US

<u>Source</u>	Average Annual Effective Dose Equivalent	
	(Sv)	(mrem)
Inhaled (Radon and Decay Products)	2000	200
Other Internally Deposited Radionuclides	390	39
Terrestrial Radiation	280	28
Cosmic Radiation	270	27
Cosmogenic Radioactivity	10	1
Rounded Total from Natural Sources	3000	300
Rounded Total from Artificial Sources	600	60
Total	3600	360
*Source: University of Michigan ¹¹		



www.padental.org

As shown in the table on the previous slide, 82% of the total average annual effective dose is from natural sources of radiation, and of that, most is from radon. Of the other 18%, the majority is from medical diagnosis and treatments, with less than one percent from nuclear power and fallout.





Effective Dose From Diagnostic X-Ray Examinations

Dental Examinations	Effective dose (mSv)
-Rectangular collimation	
Posterior bitewings: PSP or F-speed film	.005
FMX: PSP or F-speed film	.035
-Round collimation	
FMX: PSP or F-speed film	.171
FMX: D-speed film	.388
-Panoramic	.009026
-Cephalometric	.003006
-Cone-beam Imaging	.058206
-Panoramic -Cephalometric	.009026 .003006

**occupational dose limit – 50 mSv per year **non-occupational (public) dose limit -1 mSv per year

*Source: White and Pharoah⁴





Effective Dose From Diagnostic X-Ray Examinations

<u>Medical Examinations</u>	<u>Effective dose (mSv)</u>
Chest (2 views)	0.1
Cervical spine	0.20
Thoracic spine	1.0
Mammography	0.4
Extremity	0.001
Upper GI	6.0
Barium enema	8.0
CT scan – head	2.0
CT scan – chest	7.0

*Source: Mettler and Upton²



www.padental.org

Somatic effects

- Are seen in the person irradiated
- Are not transferred to future generations
- Radiation injuries can produce changes in somatic cells and result in poor health
- Somatic cells include all cells except reproductive



Genetic effects

- Are not seen in the person irradiated
- Are passed on to future generations
- Radiation injuries can produce changes in reproductive cells
- Genetic damage cannot be repaired



III. Digital Radiography

- Digital radiographic sensors and phosphor plates contact mucous membranes and must be covered with FDA approved hygienic barriers.
- Holders for digital radiographic sensors and phosphor plates must be disposable or autoclavable.





III. Digital Radiography

- The following general principles apply to radiographic sensors:
 - Digital Radiographic Sensors:
 - Cover sensor and any cords which contact mucosa or contaminated hands or gloves.
 - Prior to disinfecting:
 - Remove barrier sheaths
 - Clean organic matter from sheath and cord
 - Disinfect the sensor with a germicidal wipe or EPA registered antitubercular disinfectant. **Do not** use chlorine bleach as it is corrosive.





III. Digital Radiography

- The following general principles apply to phosphor plates:
 - Phosphor Plates:
 - Cover with protective sheath
 - Disinfect with intermediate-level disinfectant (can use 10% bleach)
 - Do not soak overnight
 - Avoid contact with:
 - Isopropyl alcohol
 - Hydrogen peroxide
 - Citrus-based cleaners
 - Hand lotions or alcohol gel sanitizers





III. Digital Radiology

Each manufacturer of digital radiographic sensors also has specific guidelines for disinfecting their sensors. Contact specific suppliers for their recommended disinfection procedures. In addition, each manufacturer has specific guidelines for sterilizing their digital sensor holders.





III. Digital Radiology Intraoral Radiography

Questions often arise concerning a comparison of digital radiography to conventional radiography:

- Patient exposure for intraoral radiography can vary depending on the KvP, ma and length of exposure for each radiograph. Typically for film at 70KvP and 7mas, an exposure of 0.2-0.3 pulses is used. For phosphor plates, a setting of 0.08-0.14 pulses is used.
- Digital radiographs would require 40-60% less exposure compared to conventional radiography.





III. Digital Radiography Comparing Cone Beam CT with Medical CT

<u>Type of Examination</u>	<u>Effective Dose (Sv)</u>
Intraoral Film (per exposure)	< 8.3
Dental Panoramic	9-26
Dental Cephalometric	3-6
Cone Beam CT- Dental- Alveolar	5-38.3
(focus field view)	
Full Mouth Series	35-388
Cone Beam CT- Craniofacial	65-599
Medical CB Maxilla and Mandible	2,000

*Source: White and Pharoah⁴



www.padental.org

IV. Quality Assurance

- Quality Assurance procedures are used to assure high quality diagnostic radiographs.
- A Quality Assurance program includes both quality control tests and quality assurance procedures.
- Quality of radiographic procedures is fundamental to the proper diagnosis and treatment of patients.



IV. Quality Assurance

An effective Quality Assurance program helps to ensure that radiation exposure to patients and equipment operators is as low as reasonably achievable (ALARA) while providing efficient, consistent, high quality diagnostic results.





IV. Maintenance and Modification of the Quality Assurance Program

- DEP regulations require that Quality Assurance program records be maintained for three years.
- Records should be sufficiently detailed for the DEP to reconstruct Quality Assurance activities.
- Review your Quality Assurance program annually and modify as needed.
- At a minimum, periodically check the X-ray beam collimation and positioning stability.
- Perform equipment maintenance as recommended by the manufacturer.





- Documentation to demonstrate compliance. There should be a written description of the program (e.g., manual).
 - Manuals should contain checklists of QA activities and results of tests.
 - Manuals should contain standards to assess quality.
 - Manuals should show how patient safety is assured.





Important considerations

1) Quality of images (clinical value)

2) Patient safety





1) Quality of Images

- <u>Contrast</u> the difference in degrees of blackness
- <u>Density</u> the overall darkness or blackness of a radiograph
- <u>Fog</u> film that has expired, been improperly stored, or has been exposed to radiation appears fogged. Fresh film appears clear with a slight blue tint.
- <u>Artifacts</u> Unwanted images that appear in film due to improper handling or patient preparation
- <u>Coverage of clinical area</u> Proper alignment of the X-ray beam will be centered over the film. Misalignment can result in cone-cut.





2) Patient Safety

- Establish and adhere to optimum exposure technique settings.
- If settings no longer yield quality images, the cause must be promptly investigated.





IV. Quality Assurance Quality Control Tests

- <u>X-ray machines</u> should be tested for minor malfunctions, output variations, collimation problems, tubehead drift, and milliamperage readings (DEP generally performs)
- <u>X-ray film</u> fresh film test can be used to determine whether film is properly stored and protected
- <u>Screens and cassettes</u> examine periodically for adequate closure, light leaks and warping
- <u>Darkroom lighting</u> use a light leak test to check for light leaks in the darkroom
- <u>Safelight test</u> used to check for proper safelight conditions





IV. Quality Assurance Quality Control Tests

- Processing equipment manual and automatic processing equipment should be carefully maintained and monitored according to the manufacturer's instructions.
- Processing solutions developer strength can be monitored by a reference radiograph; fixer can be checked by a clearing test; follow a consistent processing protocol.





IV. Quality Assurance Repeat Rate

- Establish a system to record the occurrence of repeat X-rays and the reasons why the X-ray had to be retaken.
- A repeat exposure record may help to identify equipment, operator or technique problems.





IV. Quality Assurance QA Manual Sample

3 Ring Binder to include:

- Certificates from DANB "X-Ray" test for operators to show evidence of initial competency

- Certificates from any completed continuing education courses

- Sample DEP QA program with modifications
- Sample DEP written safety program with modifications
- Repeat exposure log
- General maintenance log
- DEP inspection log

Sample Quality Assurance Documents can found on the PDA website at: www.padental.org/radiology





Instructions for Obtaining Continuing Education Credit for this Online Course

For reviewing the "Radiation Protection Update" PowerPoint, you are eligible to receive two continuing education (CE) credits that apply towards the required radiology CE credits. In order to receive two CE credits, you must pass a short quiz based on the content on this PowerPoint. If you are not able to pass the quiz, you will not receive CE credit for the course. To access the quiz, please use the link located at <u>www.padental.org/radiology</u>.

When taking the quiz, please enter your preferred email and mailing address into the fields provided on the last slide the quiz and then hit the "submit" button. Upon successful completion of the quiz, a certificate will be mailed to you in about 2-3 weeks. If you do not pass the quiz, an email will be sent to the provided email address within 1-2 weeks notifying you that you did not pass and that you will have to try again.

If you have any further questions regarding radiology continuing education, please refer to the "<u>Radiology Continuing Education Questions and Answers</u>" page, located on the PDA website, or contact the PDA Central Office at (717) 234–5941.





Bibliography

- 1. Iannucci, JM ,and Howerton, LJ. *Dental Radiography: Principles and Techniques*. 3rd ed. St. Louis: W.B. Saunders Co.; 2006.
- 2. Mettler, FA, and Upton, AC. *Medical Effects of Ionizing Radiation*. 3rd ed. Philadelphia: Sanders/Elsevier Health Sciences;2008.
- 3. Wolter, MD. A Comprehensive Review for the DANB National Exam in Radiation Health and Safety. PowerPoint. 2010.
- 4. White, SC, and Pharoah, MJ. Oral Radiology: Principles and Interpretation. 6th ed. St. Louis: Mosby/Elsevier Health Sciences; 2008.



Bibliography

- 5. <u>American Dental Association Council on Dental Benefit Programs, Council on Dental Practice,</u> <u>Council on Scientific Affairs, and U.S. Department of Health and Human Services. The Selection</u> <u>of Patients for Dental Radiographic Examinations. 2004.</u>
- 6. <u>American Dental Association Council on Scientific Affairs. The Use of Dental Radiographs:</u> <u>Update and Recommendations. JADA 2006;137(9): 1304-12.</u>
- 7. <u>Hatcher, DC. Operational Principles for Cone-Beam Computed Tomography. JADA</u> 2010:141(10suppl): 3S-6S.
- 8. <u>Ludlow, JB, Davies-Ludlow, LE, and White, SC. Patient Risk Related to Common Dental</u> <u>Radiographic Examinations: The Impact of the 2007 International Commission on Radiological</u> <u>Protection Recommendations Regarding Dose Calculation. JADA 2008; 139(9): 1237-1243.</u>
- 9. <u>Code of Federal Regulations Title 21, Table 1. U.S. Food and Drug Administration. 26. May, 2011, http://www.accessdata.fda.gov/scripts/cdrh/cfdocs/cfcfr/CFRSearch.cfm?fr=1020.30.</u>





Bibliography

- 10. <u>"Infection Control and Digital Radiography." *Air Force Surgeon General*. May 2007. http://www.afms.af/mil/shared/media/document/AFD-130329-112/pdf.</u>
- 11. <u>"Radioactivity in Nature." *The University of Michigan Health Physics Society.* <u>http://www.umich.edu/~radinfo/introduction/natural.htm.</u></u>



